



WALL MOUNTING

Use the attached plug and screws for assembly of the wall bracket.

Drill a hole using the attached drill template. (See the template to decide the size of the drill)

Individual adjustment of the hair-dryer can be done only via the rubber cord that runs in the coiled cord cable.

Make sure that the size stated (approx. 200 cm) from the floor to the lower edge of the wall bracket is received.

If you need assistance of any kind, please don't hesitate to contact us immediately.

CEILING MOUNTING

1. Start by assembling the attached hook immediately above the sitting customer.

If the ceiling is made of concrete, drill a 6 mm hole. If the material is soft, drill 9 mm. There are plugs in the attached bag.

Use the attached extra chain to lower the connection level if the ceiling height exceeds 240 cm. (See sketch)

2. After that you attach the S-hook to the hook that is fixed to the ceiling. (See sketch)

3. After that you either install electricity in close vicinity to the hook or you could use a common extension cable, stitch it to the ceiling and connect it to the closest earthed socket outlet.

You can park the hair-dryer in the ring placed around the coiled cord cable.

Individual adjustment only with the rubber cord that runs in the cable.

